

VBSS 5/10/20/100 Hz GPS Speed Sensor

User Guide







Contents

EC DECLARATION OF CONFORMITY	5
VBSS SPEED SENSOR OVERVIEW	6
INTRODUCTION	6
FEATURES	7
STANDARD INVENTORY.....	8
OPERATION	9
INTERFACING WITH THE VBSS.....	9
POWER	9
LED INDICATORS.....	10
LOCKING ONTO SATELLITES.....	12
GPS ANTENNA	12
CONFIGURING THE SPEED SENSOR. (USING THE VBSS SOFTWARE)	13
INSTALLING THE SOFTWARE	13
RUNNING THE SOFTWARE.....	13
SETTING UP THE SPEED SENSOR.....	14
<i>Diagnostics</i>	14
<i>CAN</i>	15
<i>Analogue Output</i>	16
<i>Digital Output</i>	17
<i>Digital Input</i>	18
CONFIGURING AND USING THE LAP BEACON OUTPUT	19
<i>GPS</i>	21
<i>ADAS Functionality</i>	23
<i>Info</i>	24
LOADING AND SAVING CONFIGURATION FILES	25



<i>Saving a Configuration file</i>	25
<i>Loading a Configuration file</i>	25
BUILDING AN INTERFACE CABLE FOR THE VBSS	26
DIGITAL AND ANALOGUE OUTPUTS	26
RS232 CONNECTION.....	26
LAP INPUT/ GPS COLDSTART	26
GPS COLD START	27
GPS COLDSTART.....	27
<i>Without a computer:</i>	27
<i>With a Computer:</i>	27
UPGRADING THE VBSS FIRMWARE	28
CAN OUTPUT	29
RS232 / NMEA OUTPUT	31
SPECIFICATION	32
CONNECTION DATA.....	39
CONTACT INFORMATION	40

EC Declaration of Conformity

We declare that this product has been tested to and meet the requirements of:

EC Directive 2004/104/EC

“Adapting to Technical Progress Council directive 72/245/EEC, relating to the radio interference (Electromagnetic Compatibility) of vehicles and amending directive 70/156/EEC, on the approximation of the laws of the member states relating to the type-approval of motor vehicles and their trailers.”

And has also been assessed, via Technical Construction File, by an independent DTI Competent Body and found to be in conformance with the essential requirements of:


EC Directive 89/336/EEC (and amending directives)

“Council Directive of 03 May 1989 on the approximation of the laws of the member states relating to electromagnetic compatibility.”

DTI Competent Body responsible for issuing certificate of compliance:

3C Test Ltd,
Silverstone Technology Park,
Silverstone,
Northants
NN12 8GX

VBSS Speed Sensor Overview



Introduction


The latest generation of VBSS Speed Sensor feature 5Hz, 10Hz, 20Hz, and 100Hz GPS update rates versions, all units are compatible with the DGPS Basestation for increased positional accuracy.

Based on a range of high accuracy GPS engines, the VBSS Speed Sensors can be used for non-contact sensing of velocity providing signal output data on CAN, analogue and digital, allowing easy integration with data loggers and testing applications. The analogue output can be assigned to vehicle speed, lateral acceleration, longitudinal acceleration, or lap beacon marker with user selectable scaling. The digital output can be configured as either a digital speed pulse output or a lap beacon marker.

The units all have the same small hardware footprint of only 9cm long, making mounting and transportation easy making the Speed Sensor perfect for automotive testing, motorsport, marine, telematics, and data-logging applications and the IP66 rating means that each unit is water and dustproof, allowing them to be used in a variety of conditions.

Features

- High Performance GPS Receivers: 5 – 100Hz
- CAN Bus Output of Position, Velocity, Distance, Time, Heading, Height, Vertical Velocity, Longitudinal and Lateral Acceleration, Trigger to zero distance, Trigger time, Trigger speed, Radius of Turn
- RS232 Serial Output of NMEA, position velocity and time
- User Configurable Analogue Output
- User Configurable Digital Output
- Virtual Lap Beacon Output
- Compatible with DGPS Basestation
- Rugged Deutsch ASDD autosport connector
- High quality aluminium enclosure
- IP66 rated: water and dustproof
- Wide 6.5V – 30V operating range
- Low current consumption



Standard Inventory

Description	Qty	Racelogic Part #
RLVBSS## Speed Sensor	1	VBSS05, VBSS10, VBSS20, or VBSS100
GPS Magnetic Antenna for 5,10 & 20Hz version	1	RLVBACS018
GPS Magnetic Antenna for 100Hz version	1	RLVBACS001
VBSS Speed Sensor User manual	1	VBSSMAN
CD ROM containing VBSS software	1	CDVBSS
<i>Supplied separately</i>		
VBSS Speed Sensor Interface Cable (Analogue / Digital / CAN / Serial / Power)	1	RLCAB093

Operation

Interfacing with the VBSS

If you have purchased a RLCAB49 interface cable, then connect this to the VBSS. The RLCAB49 features connections for power, input and all outputs of the VBSS.

Because the VBSS can be used in a number of ways, it is common for the end user to integrate the VBSS connector into their own wiring harness. A mating connector, Deutsch ASDD606-09PN, may be purchased from Racelogic for this purpose. Please see the section of this manual 'Building an interface cable for the VBSS'.

Before connecting power to the VBSS you should connect the GPS antenna, this is because the VBSS will look for a connected GPS antenna and automatically adjust its gain for optimum performance from the connected antenna. For more information about the GPS antenna and antenna placement see the section 'GPS Antenna'.

Power

The VBSS can be powered from a wide range of voltage sources including a Vehicle Cigar adapter, a Racelogic Ni-Mh battery pack or other source provided by the user. The supplied power cable is un-terminated. The maximum operating voltage input must not exceed 30V DC. Failure to observe this could result in damage to the VBSS.

NB: That during extended use, the VBSS case may become hot. This is normal; however it is good practice to mount the VBSS in a position where it has sufficient airflow around the case.

LED indicators

There are 3 LED indicators on the top of the VBSS to show the status of operation.

PWR: Indicates that the VBSS is powered correctly.


- GREEN LED = OK
- RED LED = power on, but box not working correctly.

SAT: Indicates the number of GPS satellites that the VBSS has in lock. When no satellites are in lock, the SAT LED flashes slowly to indicate that the VBSS is searching for satellites. When one or more satellites are in lock, the LED will pulse the satellite count repeatedly with a short delay.


- Short RED LED = NO Sats
- GREEN LED = GPS sat count
- GREEN / RED LED = GLONAS sat count (if available)

The following diagram shows an example of SAT LED pulse sequence.


Sequence showing 1 Satellite



Sequence showing 4 Satellites



Sequence showing 0 Satellites



EVENT: Flashes in time with the digital pulse output.

- Digital Output set to 'Speed': If the digital output is set to speed then the GREEN LED will flash in time with speed at a rate of 1/10th of the digital output.
- Digital Output set to 'Lap Pulse': If the digital output is configured for the Lap Pulse, then the GREEN LED pulses for 1s when the start line is triggered and the EVENT GREEN LED and SATS GREEN LED both light up for 1s if the finish line is triggered.

The EVENT LED and the GPS LED will be constantly lit RED for the duration of a coldstart.

The EVENT LED will light BLUE when the VBSS has established a good satellite lock on four or more satellites.

Locking onto Satellites

If the VBSS is having trouble locking onto satellites then please follow the checklist below for typical solutions:

- 1) Confirm that the antenna is placed in a position where it has an unobstructed view of the sky.
- 2) Check the antenna connection with the VBSS; only small amounts of dirt in the socket can cause a significant reduction in signal strength. Also check the cable at the plug and along its length for any damage.
- 3) Check that the power supply is OK.
- 4) If possible try another known working antenna, to confirm antenna functionality.
- 5) Perform a GPS coldstart and then leave the unit powered up in an open static position for at least 15minutes. See 'GPS Coldstart'.

Once the VBSS has locked onto 5 or more satellites then it will be ready for use and will output data on CAN, RS232 and the analogue and digital outputs in accordance with the default settings.


The default settings of the CAN bus is shown in the CAN format table at the end of this manual. A CAN '.dbc' data file of this default CAN format is present on the CD, this file can be loaded directly into many CAN based data acquisition systems. The default setting of the Analogue output is Velocity configured to 5V output representing 400Kph. The default setting for the Digital output is Velocity configured to 90 pulses per metre.

GPS Antenna

The GPS Antenna supplied with the VBSS is a 5v active antenna. For the best possible signal quality, it is important to maintain a clean connection between the antenna and the VBSS. Before fixing the antenna to the VBSS, ensure that there are no dust particles in either connector. Replacement antennas are available by contacting your VBSS distributor.

The antenna is a magnetic mounting type for quick and simple mounting to the vehicle roof. For optimum GPS signal reception, make sure that the antenna is fitted to the highest point of the vehicle away from any obstructions that may block satellite reception. The GPS antenna works best with a metal ground plane underneath. (e.g. The Vehicle roof)

Please also note that when using any GPS equipment, an unobstructed sky view is important. Objects in the surrounding area such as tall buildings or trees can block the GPS signal causing a reduction or loss in the number of satellites being tracked.



Configuring the Speed Sensor. (Using the VBSS Software)

Configuration of the VBSS is performed using the setup software supplied with the unit. You will need to power up the VBSS and make a connection from its RS232 to a serial com port or USB socket (via a serial to USB adapter) on your computer.

This is most easily achieved using an RLCAB49 cable, which provides a power connection and 9way D type RS232 connection from the VBSS.

Installing the software

Insert the supplied CD into the CD drive of your computer. An installation box will automatically appear, follow the on screen instructions to complete the installation of the setup software.

After installation the CD can be removed and an Icon should have appeared on your desktop that will allow you to start the VBSS software.

Running the software


First, click on the Options button to select the correct Com port on your computer.

Now click the Connect button to enter the VBSS setup screen.

NB: After changing any settings in the setup software you will need to press the write button to confirm the changes in the speed sensor.

The speed sensor can be used straight from the box and will output digital and analogue signals according to the default settings.

These settings can be changed using the VBSS software. The VBSS software allows no other operations apart from setup when connected to a Speed Sensor.



Setting up the Speed Sensor


Diagnostics

Once the software has finished connecting with the Speed Sensor, a series of setup tabs will become available underneath the main toolbar.

The default view is the 'Diagnostics' tab as shown on the left, which provides a summary of the Speed Sensor status.

Information provided on this tab are as follows:

- Sats: The number of satellites the Speed Sensor can currently see.
- UTC Time: The current UTC time.
- Latitude: The current latitude of the Speed Sensor.
- Longitude: The current longitude of the Speed Sensor.
- Speed: The current speed of the Speed Sensor.
- Analogue Output: The current Analogue output configuration.
- Digital Output: The current Digital Output configuration.
- Digital Input: The current Digital Input configuration.
- GPS Engine Update Rate: The current operating frequency.



CAN

The CAN output consists of 7 CAN messages that contain the following data channels: Satellites, Time, Latitude, Longitude, Velocity, Heading, Height, Vertical Velocity, Lap Beacon Output, Longitudinal Acceleration, Lateral Acceleration, Distance and Radius of turn.

The default CAN output of the VBSS is shown in the CAN format section at the end of this manual.

The following options can be modified from this tab:

Baud Rate:

The Baud rate can be selected from the drop down menu in the top left of the CAN tab.

The user has the choice of four common baud rate values: 125, 250, 500, 1000 Kbit, or can select a custom baud rate by selecting 'other'. The default baud rate for this output is 500Kbaud.

CAN termination Resistance:

The internal CAN termination resistance can be enabled or disabled by clicking the 'Active Termination' button. The button is highlighted with a blue colour when the CAN termination is active.

CAN Identifier value:

The CAN tab allows the user to modify the CAN IDs to be transmitted by the Speed Sensor.

Default values are the Racelogic standard Identifier values of 0x301, 0x302 0x307, but they can be modified by double clicking on the identifier value.


Standard/Extended:

To change the identifier format from standard 11bit to extended 29bit tick the 'Xtd' box in the corresponding column.

Transmission:

To switch off or on a CAN message tick or un-tick the box for the corresponding message.

NB: After making any changes you must click 'Write Settings' for the changes to be programmed into the VBSS.



Analogue Output

On this page the user can configure the analogue output of the Speed Sensor to represent the following:

Speed:

Enter the maximum for the speed range you wish to measure. Default speed is set to 400 kmh. The maximum speed at 5V can be in the range 10 – 1000 kmh.

Lap Beacon:

When this option is enabled the VBSS will output a 5V pulse for 500ms when a Start/Finish line is crossed.

The duration of the pulse in milli Seconds can be adjusted by entering a different value.

The polarity of the pulse can be changed to either a rising or falling pulse by clicking the 'Polarity' button. The image of the pulse will change to indicate the current polarity configuration.

Lateral and Longitudinal Acceleration:

Select the range you wish to use from the pull down list.

NB: After making any changes you must click 'Write Settings' for the changes to be programmed into the VBSS.

Digital Output

The Digital output of the VBSS can be set to one of 3 options, Speed, GPS Sync, or Lap Beacon.

Speed:

The speed output is configured by changing the number of pulses per metre. Default = 90 pulse per metre => 25 Hz per km/h.

A control panel for the Speed output. It features a radio button labeled 'Speed' which is selected. To its right is a text input field containing the value '90.00', followed by the text 'Pulses Per Meter'.

GPS Sync:


Selecting this option outputs a pulse every second, which is synchronised to the GPS clock.

Lap Beacon:

When this option is enabled the VBSS will output a 5V pulse for 500ms when a Start/Finish line is crossed. The duration of the pulse in milli Seconds can be adjusted by entering a different value.

A control panel for the Lap Beacon output. It features a radio button labeled 'Lap Beacon' which is selected. To its right is a text input field containing the value '500', followed by the text 'Pulse duration (ms)'. Below this is a button labeled 'Polarity' with a square wave icon.

The polarity of the pulse can be changed to either a rising or falling pulse by clicking the 'Polarity' button. The image of the pulse will change to indicate the current polarity configuration.



NB: After making any changes you must click 'Write Settings' for the changes to be programmed into the VBSS.

Digital Input

The digital input is used for the following:

GPS Coldstart:

A coldstart can be initiated by a 15 second grounding of the digital input pin whilst NOT moving (speed < 0.5 kmh). The SAT and EVENT lights will illuminate RED to confirm that a GPS coldstart is being performed.

If the DIGITAL output is NOT set to LAP BEACON.

Brake Trigger Input:

Starts the brake stop distance measurement, where the VBSS will calculate a Time and Distance for a Brake Trigger to 0Km/h test.

If the DIGITAL output IS set to LAP BEACON.


To mark the start/finish line: The digital input of the VBSS can be used to mark a start/finish line and if required a second line. If the vehicle is moving at a speed > 5kmh and a start/finish line successfully marked, the EVENT LED flashes quickly 5 times.

NB: The width of the start line and finish line by default is 25m, but can be adjusted via the Windows setup software.

To add a 2nd line:

There is also a function to add a 2nd line, for example a separate finish line, this is done by pressing and holding the event trigger button for >1.5s.

If a second line has been successfully created the SAT and EVENT LEDs flash quickly 5 times.



Configuring and using the lap beacon output

The VBSS has the ability to simulate a Lap Beacon signal when a virtual GPS Start/finish or finish line has been crossed.

The Lap Beacon output signal can be configured to come out of either the Digital or Analogue output and it is also present as a bit inversion of a bit in a message on the CAN bus output. The Beacon pulse on the analogue and digital channel are opposite polarity, this is to provide two options for a lap beacon pulse.

NB: For a Lap beacon pulse to be output by the VBSS it must first be programmed with the position of a Start/finish or Finish line.

Setting Start/Finish and Finish Lines

This can be done in a number ways:

Manually:

If the Lat Long position of the Start/Finish line is known, the values can be directly entered into the relevant boxes on the Lap Beacon Tab.


Trigger input:

To program the position of a virtual line in the Speed Sensor you must first ensure that you have a connection to the Lap Input (pin 6). This pin should be connected to one side of a momentary switch and the other side of the switch connected to the Ground pin of the VBSS, so that when the switch is pressed the Lap Input pin will be shorted to Ground.

To set a Start/finish line:

Press and immediately release the Lap input switch as you cross the start finish line. You must be moving >5km/h to do this and following the normal line along the track. The VBSS notes the point and your direction of travel at which you press the switch and then creates a virtual line perpendicular to your line of travel 25m wide.

To set a new Start/finish line simple repeat the process above.



To set a separate Finish line: press the switch as you cross the Finish line and hold the switch for >1.5 seconds before releasing. After you have set a Start/Finish or Finish line you can view the Latitude and longitude of this line position in the Lap beacon page of the setup software. If the software was already connected then press 'Connect' again to refresh the settings.

Changing the Width of a Virtual line

The Gate width of the Start/finish or Finish line is set in the Lap Beacon page. Change this by entering a new number in the edit box. Then click 'Write Settings' to program the new setting into the VBSS. This is a useful feature when two parts of a track may run very close to each other and you do not want the virtual line to be triggered by the wrong part of circuit.

GPS

DGPS Mode

This gives the user the option to select whether the Speed Sensor uses differential GPS:

None:

Differential GPS is off.

SBAS:

The Speed Sensor will use SBAS differential corrections.

SBAS differential corrections are received from the nearest Geo-stationary GPS-SBAS satellite, when it is view of the VBSS GPS antenna.

RTCM:

The Speed Sensor will use RTCM differential corrections.

RTCM corrections can be input into the VBSS via a Racelogic telemetry module and a locally placed Base station.

Contact Racelogic or your local agent for more details.

SMI Level


This option allows the user to change the smoothing level of the GPS data.

For high dynamic applications such as brake stop testing where less smoothing is required, this should be set to High (High Dynamics).

For less dynamic applications which require the GPS data to be smoothed, it should be set to Low (Low dynamics).

GPS Engine Update Rate

Change the operating frequency of the GPS engine.



Serial Output

The Serial Output screen allows the user to configure the format, content and data rate of the serial stream transmitted by the Speed Sensor.

Baud Rate:

The required serial baud rate can be selected from this drop down menu.

Serial Mode:

This selects whether the Speed Sensor outputs data in the Racelogic format or the NMEA message format.

NMEA Messages


If the NMEA message format is selected, more options become available:

Update Rate:

The update rate of the NMEA messages can be changed using this drop down list.

Message Selection:

NMEA messages can be selected and deselected for transmission by checking and unchecking the boxes next to each message type.



Note: If a low Baud rate and a high update rate is selected then it could be possible to select more NMEA messages than it will be possible to output.


ADAS Functionality

(Advanced Driver Assistance System)

To enable ADAS remote mode the user must power up the Speed Sensor and connect to a PC or Laptop via an RLCAB01 cable and run the Speed Sensor Software. After connecting to the unit, click on the Serial Output tab and select “ADAS remote mode”.

Ticking “ADAS remote mode” configures the Speed Sensor to output Racelogic serial data for use with ADAS. The Speed Sensor will calculate its positional and dynamic data and send this information on its serial port which can be transmitted to a local VBOX via radio telemetry module. The addition of this functionality enables the user to operate an ADAS system using the Speed Sensor instead of a second VB3i data logger.

For further information on Advanced Driver Assistance Systems, please refer to the Racelogic ADAS manual.



Info

The info screen provides information about the connected Speed Sensor.

Unit Type:

Which unit type is currently connected.

Serial number:


The serial number of the connected unit.

F/W Version:

This gives the firmware version of the connected Speed Sensor.

GPS Version:

This gives the firmware version of the GPS engine in the connected Speed Sensor.



Loading And Saving Configuration files

The configurable settings of a VBSS can be saved to a file. The software also allows a configuration file to be loaded enabling quick and easy configuration of the VBSS.

Saving a Configuration file.

- Run the VBSS software
- Connect a powered VBSS to the PC via a RS232 connection
- Click the 'Connect' button in the VBSS software to start communications with the VBSS.
- Configure the VBSS as required.
- Go to the 'Options' menu
- Highlight the 'Configuration' option
- Then click 'Save'
- The standard Windows save window will appear where you can select a file name and file destination.

The file will automatically be given the extension .rlcfg.

Loading a Configuration file.

- Run the VBSS software
- Connect a powered VBSS to the PC via a RS232 connection
- Click the 'Connect' button in the VBSS software to start communications with the VBSS.
- Go to the 'Options' menu
- Highlight the 'Configuration' option
- Then click 'Load'
- The standard Windows Browse window will appear where you can select and load an '.rlcfg' file in to the software.
- Now click 'Write Settings' to apply the configurations from this loaded file into the VBSS

Building an interface cable for the VBSS

If you are building your own interface cable for the VBSS it is worthwhile adding the RS232 connection and the Lap input connection. Particularly as the Lap input provides a method of performing a GPS coldstart.


Digital and Analogue outputs

It is advisable to use a screened cable on the Analogue and Digital output for the best noise immunity, making sure that the ground is connected to the shielding of the screened cable.

RS232 Connection

Connect the pins shown in the table to a Female 9 way D-type connector.

VBSS		9 Way D-Type	
Pin		Pin	
8 Tx	=====	2 Rx	
1 Rx	=====	3 Tx	
9	=====	5	



PIN D Female
VIEW FACING SOCKETS

Lap Input/ GPS Coldstart

Connect a momentary switch to the pins shown in the table.

VBSS		Momentary push to make switch	
Pin		Pin	
6	=====	1 signal	
9	=====	2 Ground	

GPS Cold Start

GPS Coldstart

This forces the GPS engine to reset its downloaded almanac of current satellite position. This can be used if the Speed sensor is having trouble locking onto satellites. This can be caused by the Speed sensor not having been used for a period of time or if it was last used a long distance away from your current point. A GPS satellite Almanac is relevant for about 3- 4weeks, so if it has not been used or updated within that time it can cause the GPS engine to struggle. After performing a GPS Cold start leave the Speed sensor powered up in a static situation where the antenna has an unobstructed view of the skies, for 15 minutes.

Once the Speed sensor has downloaded the new almanac it is much quicker to re-acquire satellites in noisy situations such as near trees buildings and bridges. Also it is much quicker to acquire satellites on power-up.

There are two ways to perform a GPS coldstart on the VBSS, with or without the use of a computer.


Without a computer:

Connect the Lap Beacon input to ground for 15 seconds, the SAT and EVENT lights will then come on to indicate that the GPS coldstart is being performed. This is a very useful facility so it should be noted that if you are making your own loom it would be worth fitting a cable into the Lap Beacon pin position even if you have no need for the Lap Beacon facility on this product.

With a Computer:

To cold start the GPS engine in the Speed sensor using a computer, connect the RS232 port to a computer and run the VBSS set up software which is supplied with the unit. Press 'Connect' to start the communications, then select the 'Cold start' option, the SAT and EVENT lights will then come on to indicate that the GPS coldstart is being performed.

NB: The VBSS main screen and software functions are only applicable to the Speed Sensor.



Upgrading the VBSS Firmware

Firmware refers to the operating software inside the VBSS Speed Sensor. The firmware is responsible for all of the functions within the VBSS and from time to time, firmware updates will be released by Racelogic to improve or enhance the way that the VBSS works. The latest firmware will always be available on the Racelogic web site in the downloads directory:

<http://www.racelogic.co.uk/2003/VBSS/downloads.htm>

It is recommended to check the web site periodically for updates. The VBSS upgrade files have a “.ruf” file extension. To upgrade the VBSS firmware, download the latest firmware file from the Racelogic web site and copy this file onto your PC. If you have done a full VBSS CD installation then you will have the upgrade programme automatically installed in the Utilities folder of VBSS folder. If not then this can also be downloaded from the website. Connect your PC to the VBSS via the VBSS serial lead and apply power to the VBSS.

Either ‘double click’ on the ‘.ruf’ upgrade file, which auto runs the Upgrader software, or run the Upgrader software and load in the ‘.ruf’ firmware upgrade file. Then follow the onscreen instructions and the VBSS firmware will be upgraded.

At the end of the process power down the VBSS when prompted, before further use. During the upgrade process an upgrade log file will have been created. This log file can be emailed to the support address below should any problems arise.

If you have any questions regarding the upgrade of the VBSS, please do not hesitate to contact: support@racelogic.co.uk

CAN output

The following details the CAN output of the VBSS##

ID*	Update Rate	Data Bytes							
		1	2	3	4	5	6	7	8
0x301	100ms	(1)Sats in view	(2) Time since midnight UTC			(3) Position – Latitude MMMM.MMMMM			
0x302	100ms	(4) Position – Longitude MMMMM.MMMMM			(5) Speed. (Knots)		(6) Heading (Degrees)		
0x303	100ms	(7) Altitude. WGS 84. (Metres)		(8) Vertical velocity. (M/S)		Unused	(9) Status	(10) Status2	
0x304	100ms	(11) Distance from Brakettrigger to 0 Kmh (Meters)			(12) Longitudinal Accel. (G)		(13) Lateral Accel. (G)		
0x305	100ms	(11) Distance travelled since VBSS reset (Metres)			Time taken from brake trigger to 0 Kmh		Trigger Speed		
0x306	100ms	Unused		(14) Radius of Turn (meters)					
0x307	100ms	(15) Position – Latitude DD.DDDDDDD			(16) Position – Longitude DD.DDDDDDD				

*Default IDs shown above.

- (1) Sats: If Satellites in view < 3 then only Identifier 0x301 transmitted and bytes 2 to 8 are set to 0x00.
- (2) Time since midnight: This is a count of 10ms intervals since midnight UTC.
(5383690 = 53836.90 seconds since midnight or 14 hours, 57 minutes and 16.90 seconds).
- (3) Position: Latitude (mmmm.mmmmm) * 100,000 (311924579 = 51 Degrees, 59.24579 Minutes North).
This is a true 32bit signed integer, North being positive.
- (4) Position: Longitude (mmmmm.mmmmm)* 100,000 (11882246 = 0 Degrees, 58.82246 Minutes West).
This is a true 32bit signed integer, West being positive.
- (5) Velocity: 0.01 knots per bit.
- (6) Heading: 0.01° per bit.
- (7) Altitude: 0.01 meters per bit, signed.

(8)	Vertical Velocity:	0.01 m/s per bit, signed.
(9)	Status:	8 bit unsigned char. Bit 2 always set.
(10)	Status2:	8 bit unsigned char. Bit 0 is always set, Bit 1 = Lapmarker, Bit 3=brake test started, Bit 4 = Brake trigger active, Bit 5 = DGPS active
(11)	Distance:	Distance from brake trigger to zero in meters * 12800.
(12)	Longitudinal Acc:	0.01G per bit, signed.
(13)	Lateral Acc:	0.01G per bit, signed.
(14)	Radius of Turn:	32-bit signed * 100.
(15)	Position	Latitude (DD.DDDDDDD) * 10,000,000 (519874298 = 51.9874298 Degrees, North). This is a true 32bit signed integer, North being positive.
(16)	Position:	Longitude (DD.DDDDDDD) * 10,000,000 (11882246 = 1.9803743 Degrees, West). This is a true 32bit signed integer, West being positive.

RS232 / NMEA output

The RS232 output is present to provide a connection to a computer for configuring the settings of the VBSS through the VBSS setup software. It also can output NMEA format messages. The VBSS can output 8 types of NMEA messages, the most commonly used are GPGGA and GPVTG, the contents of which are shown below.

`$GPGGA,hhmmss.ss, Latitude, N, Longitude, E, FS, NoSV, HDOP, msl, m, Altref, m, DiffAge, DiffStation*cs<CR><LF>`

Name	ASCII String		Units	Description	
	Format	Example			
\$GPGGA	string	\$GPGGA		Message ID	GGA protocol header
hhmmss.ss	hhmmss.sss	092725.00161229.487		UTC Time	Current time
Latitude	dddmm.mmmm	4717.113993723.2475		Latitude	Degrees + minutes
N	character	N		N/S Indicator	N=north or S=south
Longitude	dddmm.mmmm	00833.9159012158.3416		Longitude	Degrees + minutes
E	character	WE		EW indicator	E=east or W=west
FS	1 digit	1		Position Fix Indicator	See Table 41
NoSV	numeric	078		Satellites Used	Range 0 to 12
HDOP	numeric	1.001		HDOP	Horizontal Dilution of Precision
Msl	numeric	499.69.0	m	MSL Altitude	
M	character	M		Units	Meters
Altref	blank	48.0	m	Geoid Separation	
M	blank	M		Units	Meters
DiffAge	numeric		second	Age of Differential Corrections	Blank (Null) fields when DGPS is not used
DiffStation	numeric	0		Diff. Reference Station ID	
Cs	hexadecimal	*5B *18		Checksum	
<CR> <LF>					End of message

\$GPVTG,cogt,T,cogm,M,sog,N,kph,K*cs<CR><LF>

Name	ASCII String		Units	Description	
	Format	Example			
\$GPVTG	string	\$GPVTG		Message ID	VTG protocol header
cogt	numeric	77.52	degrees		Course over ground (true)
T	character	T		fixed field	True
cogm	Blank			Course over ground (magnetic).	Not output (empty)
M	character	M		fixed field	Magnetic
sog	numeric	0.004	knots		Speed over ground
N	character	N			
kph	numeric	0.008	km/h	Speed	
K	character	K		K	Kilometers per hour - fixed field
cs	hexadecimal	*0B		Checksum	
<CR> <LF>					End of message

Specification

5Hz Speed Sensor (VBSS05): GPS Specifications			
Velocity		Distance	
Accuracy	0.2 Km/h	Accuracy	0.05% (<50cm per Km)
Units	Km/h or Mph	Units	Metres / Feet
Update rate	5 Hz	Update rate	5 Hz
Maximum velocity	1000 Mph	Resolution	1cm
Minimum velocity	0.1 Km/h	Height accuracy	10 Metres 95% CEP**
Resolution	0.01 Km/h		
Latency	>160ms		
Absolute Positioning		Time	
Accuracy	5m 95% CEP**	Resolution	0.01 s
Accuracy w/ SBAS DGPS	1.5m 95% CEP**	Accuracy	0.01 s
		Brake stop Accuracy (Trigger Activated)	
Update rate	5 Hz	Accuracy	N/A
Resolution	1.8 cm		
Heading		Acceleration	
Resolution	0.01°	Accuracy	1.00%
Accuracy	0.2°	Maximum	4 G
		Resolution	0.01 G
		Update rate	5 Hz
Definitions			
** CEP = Circle of Error Probable	95% CEP (Circle Error Probable) means 95% of the time the position readings will fall within a circle of the stated radius		

10Hz Speed Sensor (VBSS10): GPS Specifications			
Velocity		Distance	
Accuracy	0.1 Km/h	Accuracy	0.05% (<50cm per Km)
Units	Km/h or Mph	Units	Metres / Feet
Update rate	10 Hz	Update rate	10Hz
Maximum velocity	1000 Mph	Resolution	1cm
Minimum velocity	0.1 Km/h	Height accuracy	6 Metres 95% CEP**
Resolution	0.01 Km/h	Height accuracy with DGPS	2 Metres 95% CEP**
Latency	41.5ms		
Absolute Positioning		Time	
Accuracy	3m 95% CEP**	Resolution	0.01 s
Accuracy with SBAS DGPS	1.8m 95% CEP**	Accuracy	0.01 s
Accuracy w/ Basestation RTCM DGPS	40cm 95% CEP**		
Accuracy with Basestation DGPS + GPS Upgrade (RLVBUP30)	20cm 95% CEP**		
Update rate	10 Hz	Brake Stop Accuracy (Trigger Activated)	
Resolution	1.8 cm	Accuracy	±20cm
Heading		Acceleration	
Resolution	0.01°	Accuracy	0.50%
Accuracy	0.1°	Maximum	20 G
		Resolution	0.01 G
		Update rate	10 Hz
Definitions			
** CEP = Circle of Error Probable	95% CEP (Circle Error Probable) means 95% of the time the position readings will fall within a circle of the stated radius		

20Hz Speed Sensor (VBSS20): GPS Specifications			
Velocity		Distance	
Accuracy	0.1 Km/h	Accuracy	0.05% (<50cm per Km)
Units	Km/h or Mph	Units	Metres / Feet
Update rate	20 Hz	Update rate	20Hz
Maximum velocity	1000 Mph	Resolution	1cm
Minimum velocity	0.1 Km/h	Height accuracy	6 Metres 95% CEP**
Resolution	0.01 Km/h	Height accuracy with DGPS	2 Metres 95% CEP**
Latency	41.5 ms		
Absolute Positioning		Time	
Accuracy	3m 95% CEP**	Resolution	0.01 s
Accuracy with SBAS DGPS	1.8m 95% CEP**	Accuracy	0.01 s
Accuracy w/ Basestation RTCM DGPS	40cm 95% CEP**		
Accuracy with Basestation DGPS + GPS Upgrade (RLVBUP30)	20cm 95% CEP**		
Update rate	10 Hz	Brake Stop Accuracy (Trigger Activated)	
Resolution	1.8 cm	Accuracy	±10cm
Heading		Acceleration	
Resolution	0.01°	Accuracy	0.50%
Accuracy	0.1°	Maximum	20 G
		Resolution	0.01 G
		Update rate	20 Hz
Definitions			
** CEP = Circle of Error Probable	95% CEP (Circle Error Probable) means 95% of the time the position readings will fall within a circle of the stated radius		

100Hz Speed Sensor (VBSS100): GPS Specifications			
Velocity		Distance	
Accuracy	0.1 Km/h	Accuracy	0.05% (<50cm per Km)
Units	Km/h or Mph	Units	Metres / Feet
Update rate	100 Hz	Update rate	100Hz
Maximum velocity	1000 Mph	Resolution	1cm
Minimum velocity	0.1 Km/h	Height accuracy	6 Metres 95% CEP**
Resolution	0.01 Km/h	Height accuracy with DGPS	2 Metres 95% CEP**
Latency	6.75ms		
Absolute Positioning		Time	
Accuracy	3m 95% CEP**	Resolution	0.01 s
Accuracy with SBAS DGPS	>1.8m 95% CEP**	Accuracy	0.01 s
Accuracy with Basestation RTCM DGPS	40cm 95% CEP**		
Update rate	100 Hz	Brake stop Accuracy (Trigger Activated)	
Resolution	1.8 cm	Accuracy	+/- 1.8 cm
Heading		Acceleration	
Resolution	0.01°	Accuracy	0.50%
Accuracy	0.1°	Maximum	20 G
		Resolution	0.01 G
		Update rate	100 Hz
Definitions			
** CEP = Circle of Error Probable	95% CEP (Circle Error Probable) means 95% of the time the position readings will fall within a circle of the stated radius		



Outputs	
CAN Bus	
Output Data Rate	125Kbit, 250Kbit ,500Kbit & 1Mbit selectable baud rate. Un-terminated CAN node.
Data available	Position, vehicle speed, heading, lateral acceleration, longitudinal acceleration, satellite count, time, radius of turn, altitude.
RS232	
Output Data Rate	Dependent on configured rate, max + GPS update rate
Data Available	NMEA \$GPGGA and \$GPVTG messages at various configurable Baud rates
Analogue	
Output Data	0 to 5v DC
Data Available	Either Speed, Lateral Acceleration, Longitudinal Acceleration, or Lap Beacon
Digital Output	
Output Data Rate	Low = 0v, High = 5v, 10-1000 pulses per revolution, Max frequency 4.4Khz
Data Available	Speed, Lap Beacon, or GPS synch pulse

Inputs	
Power	
Input Voltage range	6.5v – 30v DC
Power	3.7w Max (except VBSS05: 2w Max)
GPS Antenna	3V Active Antenna (inc)
Digital Input	Cold Start Activate / Set Lap beacon Position
LED	Power, Satellite Count, Event Out

Environmental and physical			
Weight	Approx 250g (Except VBSS05: 190g)	Operating temp	-30°C to +70°C
		Storage temp	-40°C to +85°C
Size	90mm x 65mm x 31.85mm	Connectors	Deutsch ASDD Autosport Rated IP66

Hardware / Software Support	
Hardware	One Year Support Contract
Software	Lifetime Support Contract: valid for a minimum of 5 years from the date of purchase and limited to original purchaser. Contract includes telephone / email technical support provided by local VBSS distributor and firmware / software upgrades where applicable.

Connection Data



9-PIN Deutsch Connector

Main Connector (Deutsch Autosport)

Pin	I/O	Function
1	I	RS232 Rx
2	I	+8V to +30V Power. Ignition switched feed
3	I/O	CAN Low
4	I/O	CAN High
5	O	Analogue Output
6	I	Lap Marker Input / Brake Trigger Input
7	O	Speed Pulse / Lap Beacon
8	O	RS232 Tx
9	I	Ground

