



## Vehicle CAN Database

Nissan  
370Z

## Overview

Racelogic have acquired CAN signals for customers to use with VCI (Vehicle CAN Interface) products. This information is available by listening on the relevant CAN bus on the vehicle and interpreting the messages to form easy to use information which is then available for data logging.

## VBox Video HD2 Users

Users of VBox Video HD2 will find this vehicle available to be selected via the VBox Video setup software which can be downloaded from our website. The software is supplied with instant access to the CAN information for a large array of vehicles and is kept automatically up to date as new vehicles and signals are added (Subject to internet connection).

To start using HD2 with your vehicle simply follow the steps below:

1. Open VBox Video Setup
2. Click the "Settings" menu option
3. Select "CAN"
4. Select "Vehicle database" under "Source"
5. Select "Nissan" and "370Z"
6. Tick the signals you wish to use

## Use with other Racelogic Products

Users of other Racelogic products will need to download a file from our website here:

<https://vboxmotorsport.co.uk/index.php/en/customer-area/vehicle-can-database>

Select "Nissan" and "370Z" from the dropdown selection to download the relevant file.

Refer to the user manual of your product for details on how to use this file.

## Wiring Connection

On this vehicle all information is available via the OBD-II connector, this uses the standard pins of CAN High on pin 6 and CAN low on pin 14.

PLEASE NOTE: This information is provided as a general guide to CAN Bus wire colours only and colours may be subject to change without notice. Racelogic accepts no responsibility for damage or malfunction caused by incorrect wiring of its products to a vehicle. Any connection to a vehicle CAN Bus should be done by a trained automotive technician.

### CAN bus Connection

The CAN bus must be configured at a baud rate of 500k.

### Cable - VBox Video HD2

To connect the HD2 system to an OBDII port, an [RLCAB069L](#) cable must be used. [Click here](#) for a cable drawing including PIN outs for the RLCAB069L.

### Cable - Other Racelogic Products

To connect between your racelogic product and the vehicle a standard OBD Cable is available, if this was not supplied with the product please contact us for details.

## Available CAN Channels

The following signals are available for selection:

Signal	Default Units
Brake Position	
Clutch Position	
Coolant Temperature	°C
Door Open - Front Left	
Door Open - Front Right	
Engine Speed	rpm
Fuel Consumption	mm <sup>3</sup>
Full Beam	
Gear	
Handbrake	
Headlights	
Ignition - Acc Position	
Ignition - Run Position	
Ignition - Starter Position	
Ignition On	
Indicated Lateral Acceleration	
Indicated Longitudinal Acceleration	
Indicated Vehicle Speed	km/h
Indicator Left	
Indicator Right	
Side Lights	
Steering Angle	
Steering Rate	°/s
Throttle Position	%
Wheel Speed FL	km/h
Wheel Speed FR	km/h
Wheel Speed RL	km/h
Wheel Speed RR	km/h
Yaw Rate	

Note: not all signals listed above will be applicable to all variants of this vehicle and so may not be available for your specific vehicle.

## Support

If any data contained in this document is incorrect or for further support please visit our website here: <http://www.vboxmotorsport.co.uk/support>