

KTM X-Bow



### Overview

Racelogic have acquired CAN signals for customers to use with VCI (Vehicle CAN Interface) products. This information is available by listening on the relevant CAN bus on the vehicle and interpreting the messages to form easy to use information which is then available for data logging.

## VBox Video HD2 Users

Users of VBox Video HD2 will find this vehicle available to be selected via the VBox Video setup software which can be downloaded from our website. The software is supplied with instant access to the CAN information for a large array of vehicles and is kept automatically up to date as new vehicles and signals are added (Subject to internet connection).

To start using HD2 with your vehicle simply follow the steps below:

- 1. Open VBox Video Setup
- 2. Click the "Settings" menu option
- 3. Select "CAN"
- 4. Select "Vehicle database" under "Source"
- 5. Select "KTM" and "X-Bow"
- 6. Tick the signals you wish to use

# Use with other Racelogic Products

The signals used for this vehicle/ECU are not available for use in non HD2 Products.



# Wiring Connection

High speed CAN information is available at the OBD port on the KTM X-Bow, however the pins for CAN high and Low are different to the industry standard.

CAN High - Pin 3 CAN Low - Pin 11

PLEASE NOTE: This information is provided as a general guide to CAN Bus wire colours only and colours may be subject to change without notice. Racelogic accepts no responsibility for damage or malfunction caused by incorrect wiring of its products to a vehicle. Any connection to a vehicle CAN Bus should be done by a trained automotive technician.

#### **CAN** bus Connection

The CAN bus must be configured at a baud rate of 500k.

#### Cable - VBox Video HD2

To connect the HD2 system to a vehicle CAN bus system using a bare wire, an <a href="RLCAB015L">RLCAB015L</a> cable must be used.

<u>Click here</u> for a cable drawing including PIN outs for the RLCAB015L.

Note: If the connection needs to be made using a bare wire interface with the CAN High and Low outputs of the vehicle, we strongly recommend contacting a qualified auto-electrician to perform the fitting.

#### Cable - Other Racelogic Products

The signals used for this vehicle/ECU are not available for use in non HD2 Products.



## Available CAN Channels

The following signals are available for selection on our HD2 Product, these signals may not be available on other Racelogic Products:

Signal	Default Units
Boost Pressure	bar
Brake Pressure	bar
Coolant Temperature	°C
Engine Speed	rpm
Gear	
Gear - Automatic	
Indicated Lateral Acceleration	
Indicated Longitudinal Acceleration	m/s <sup>2</sup>
Oil Temperature	°C
Throttle Position	%
Transmission Oil Temperature	°C
Wheel Speed FL	km/h
Wheel Speed FR	km/h
Wheel Speed RR	km/h
Yaw Rate	

Note: not all signals listed above will be applicable to all variants of this vehicle and so may not be available for your specific vehicle.

# Support

If any data contained in this document is incorrect or for further support please visit our website here: <a href="https://www.vboxmotorsport.co.uk/support">https://www.vboxmotorsport.co.uk/support</a>